How to Order an HSS Blade

Use the chart below to determine the HSS blade best suited for your application.
You will need to know the following:

1. Determine your tool range (To do this in mere seconds, go to **ezburr.com**, click on **E-Z Tool Calculator**
2. Determine the material group you are cutting
3. Choose Front & Rear Cutting or Rear Cutting Only

Material Type:	Cast Iron: Grey, Ductile, Nodular		Aluminum: Free Machining: 1118, 1215,12L14; Medium Carbon: 1030, 1040, 1050; Alloy: 4140, 5140, 8640, 4340, 4330		Stainless: 303, 416, 420; Low Carbon: 1008, 1010, 1018, 1020, 1025, 1522; Structural Steel: A36, A285, A516		High Temp Alloys: Hastelloy, Inconel, Rene	
Material Machinability:	STANDARD		GOOD		TOUGH (-T)		DIFFICULT (-D)	
Tool Range / Cutting Styles	Front & Rear	Rear Only	Front & Rear	Rear Only	Front & Rear	Rear Only	Front & Rear	Rear Only
CAR0400 - CAR0880 (W/Suffix) Replacement Blade #	-B N/A	-R N/A	-B N/A	-R N/A	-B N/A	-R N/A	-B N/A	-R N/A
EZL0093 - EZL0118 (W/Suffix) Replacement Blade #	-01 L1A-01	-07 L1A-07	-02 L1A-02	-08 L1A-08	-05 L1A-05	-11 L1A-11	-05 L1A-05	-11 L1A-11
EZL0122 - EZL0153 (W/Suffix) Replacement Blade #	-01 L1B-01	-07 L1B-07	-02 L1B-02	-08 L1B-08	-05 L1B-05	-11 L1B-11	-05 L1B-05	-11 L1B-11
EZL0156 - EZL0177 (W/Suffix) Replacement Blade #	-01 L2A-01	-07 L2A-07	-02 L2A-02	-08 L2A-08	-05 L2A-05	-11 L2A-11	-05 L2A-05	-11 L2A-11
EZL0187 - EZL0236 (W/Suffix) Replacement Blade #	-01 L2B-01	-07 L2B-07	-02 L2B-02	-08 L2B-08	-05 L2B-05	-11 L2B-11	-05 L2B-05	-11 L2B-11
EZL0250 - EZL0334 (W/Suffix) Replacement Blade #	-01 L3A-01	-07 L3A-07	-02 L3A-02	-08 L3A-08	-05 L3A-05	-11 L3A-11	-05 L3A-05	-11 L3A-11
EZL0343 - EZL2000 (W/Suffix) Replacement Blade #	-01 L3B-01	-07 L3B-07	-02 L3B-02	-08 L3B-08	-05 L3B-05	-11 L3B-11	-05 L3B-05	-11 L3B-11

If you need further assistance in ordering an HSS blade from E-Z Burr Tool Company, email your request to info@ezburr.com or call 1.800.783.2877.